



TT RGB Plus Alexa Skill Settings SOP

Go to www.amazon.com and log in use a Amazon account.


Next to the search bar, Click the “All” tab and select “Alexa Skills”.




Search “TT RGB Plus” and Select this skill.




Click “Enable”.



The skill requires access to the country and postal code that is configured with the Alexa device. Please allow and click “Save Permissions”.




Notice: Please allow this page to show pop-ups, to launch TT RGB Plus “Login/Sign Up” page.



Login with TT DPS G (SPM) account.

TT RGB PLUS ECOSYSTEM

The image shows a login interface for the TT RGB PLUS ECOSYSTEM. The background is a dark, high-quality photograph of a gaming setup, including a monitor displaying the TT RGB PLUS logo, a keyboard, a mouse, and a PC tower with RGB lighting. In the foreground, there is a dark grey login panel with the following elements:

- An "Email" field containing the text "tony.peng@thermaltake.com".
- A "Password" field with a masked password of seven asterisks.
- An orange "Login" button.
- A blue "Sign Up" button.

• If you already have TT DPS G account (SPM) No need to register again, log in directly to use.
• You must log into the TT RGB Plus PC App or TT DPS G PC App at least once to register and control your RGB devices with the TT RGB Plus Skill.